

#5557TCA-LK - Tubular Control Arms Instructions

for 1955-57 Fullsize Chevy Car

Parts List:

Left Lower Control Arm Assembly Right Lower Control Arm Assembly 1 ea

5/16-18 Speed Nuts 4 ea 5/16-18x1 1/2 Gr. 8 Bolts 4 ea 5/16 Flat Washers 4 ea


5/16 Lock Washers

Warning:

Do not remove the cross shaft bolts. They are installed with Loctite. Removing the cross shaft bolts will void the warranty.

Instructions:

- 2. Install the new lower control arm assemblies. The long tube with the sway bar mounting tab will be towards the front of the car. CPP recommends using new ball joints (part # FA219).
- 3. Install the coil springs. CPP recommends using new coil springs (part #FCS638 stock or #FCS638D 2" drop).
- 4. Using the new 5/16 hardware, install the front shocks. CPP recommends using new shocks (part #KY-1001).
- 5. Have the car professionally aligned.



© Classic Performance Products, Inc. 2015 All rights reserved. This document may not be repro duced without prior written permission of CPP.

5/8" grade 5 | 154lb/ft NOTE: With 18" and larger wheels we recommend 1/2" wheel studs. The larger the wheel diameter, the greater the force is on the wheel studs. Please inquire about replacement wheel stud kits available from CPP.

7/16" grade 8 78lb/ft

9/16" grade 8 169lb/ft

19lb/ft 54lb/ft

78lb/ft