


## #7387CNK - Installation Instructions

### for 1973-87 Chevy Truck C-Notch Kit

#### Instructions:

1. Remove the original bump stop and bump stop mount from the frame.
2. Using the C-notch bracket as a guide, mark the portion of the frame that will need to be cut in order for the C-notch to be installed. The bump stop should be aligned directly with the original bump stop location.
3. Cut the portion of the frame that needs to be removed so the C-notch can be installed. You may need to support the frame so that it does not bend after it is cut.
4. Position the C-notch on the frame. Using the C-notch as a guide drill 1/2 inch holes into the frame.
5. Using the 1/2 inch hardware bolt the C-notch to the frame.
6. Using the 3/8 inch hardware bolt the new bump stop to the bottom of the C-notch.



#### GENERAL TORQUE SPECIFICATIONS:

|               |          |               |          |
|---------------|----------|---------------|----------|
| 1/4" grade 5  | 10lb/ft  | 1/4" grade 8  | 14lb/ft  |
| 5/16" grade 5 | 19lb/ft  | 5/16" grade 8 | 29lb/ft  |
| 3/8" grade 5  | 33lb/ft  | 3/8" grade 8  | 47lb/ft  |
| 7/16" grade 5 | 54lb/ft  | 7/16" grade 8 | 78lb/ft  |
| 1/2" grade 5  | 78lb/ft  | 1/2" grade 8  | 119lb/ft |
| 9/16" grade 5 | 114lb/ft | 9/16" grade 8 | 169lb/ft |
| 5/8" grade 5  | 154lb/ft | 5/8" grade 8  | 230lb/ft |

NOTE: With 18" and larger wheels we recommend 1/2" wheel studs. The larger the wheel diameter, the greater the force is on the wheel studs. Please inquire about replacement wheel stud kits available from CPP.

© Classic Performance Products, Inc. 2013  
All rights reserved. This document may not be reproduced without prior written permission of CPP.